



Operating Instructions

Air Conditioner



Model No.

Indoor Unit

CS-MXS9UKZ

CS-MXS12UKZ

CS-MXS15UKZ

CS-MXS18UKZ

CS-MXS24UKZ

Outdoor Unit

CU-2XS20UKZ

CU-3XS27UKZ

CU-4XS30UBZ

CU-4XS34UBZ

Operating Instructions Air Conditioner

2-13

Before operating the unit, please read these operating instructions thoroughly and keep them for future reference. The included Installation Instructions should be kept and read by the installer before installation. Remote control is packaged in the indoor unit and removed by the installer before installation.

操作說明書 空調器

14-25

在操作空調器前，請細讀此操作說明，並保存此書以備日後參考。
附帶的安裝說明須保存並請安裝人員在安裝前閱讀。
遙控器包裝在室內機箱子裏並請安裝人員在安裝前取出。

English

中文



ACXF55-17770

Provide fast cooling, maximum comfort,
clean air and optimise energy saving


Human activity sensor

- Area Search
- Activity Detection
- Absence Detection

Sunlight sensor and
remote control receiver


Use remote
control within 8 m
from the remote
control receiver of
the indoor unit.

Flexibility to connect
Single Split System or
Multi Split System Air
Conditioner to suit your
needs. For complete
product features, please
refer to catalogue.




Quick Guide

Inserting the batteries




- 1 Pull out the back cover of remote control.
- 2 Insert AAA or R03 batteries.
- 3 Close the cover.

A Clock setting



- 1 Press and set the time .
 - Press and hold for approximately 5 seconds to show time in 12-hour (am/pm) or 24 hour indication.
- 2 Confirm .



Thank you for purchasing
Panasonic Air Conditioner.

Table of contents

Safety precautions.....	4-5
How to use.....	6-7
To learn more	8-9
Cleaning instructions.....	10
Troubleshooting.....	11-13
Information.....	26

Accessories

- Remote control
- AAA or R03 batteries × 2
- Remote control holder
- Screws for remote control holder × 2

The illustrations in this manual are for explanation purposes only and may differ from the actual unit. They are subject to change without notice for future improvement.

English

Basic operation

- ① Press **MODE** to select the desired mode.


AUTO → COOL → DRY

- ② Press **OFF/ON** to start/stop the operation.



- Please note that the **OFF** indication is on display to start the unit.

- ③ Select the desired temperature.



Selection range:
16.0 °C ~ 30.0 °C /
60 °F ~ 86 °F.

- Press and hold  for approximately 10 seconds to switch the temperature indication in °C or °F.

Safety precautions

To prevent personal injury, injury to others or property damage, please comply with the following:
Incorrect operation due to failure to follow instructions below may cause harm or damage, the seriousness of which is classified as below:

This appliances is not intended for accessibility by the general public.


	WARNING	This sign warns of death or serious injury.
---	----------------	---

	CAUTION	This sign warns of injury or damage to property.
---	----------------	--

The instructions to be followed are classified by the following symbols:

	This symbol denotes an action that is PROHIBITED .
---	---

	These symbols denote actions COMPULSORY .
---	--



WARNING

Indoor unit and outdoor unit



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Please consult authorised dealer or specialist to clean the internal parts, repair, install, remove and reinstall the unit. Improper installation and handling will cause leakage, electric shock or fire.

Confirm with authorised dealer or specialist on usage of any specified refrigerant type. Using refrigerant type other than the specified may cause product damage, burst and injury etc.



Do not use means to accelerate the defrosting process or to clean, other than those recommended by manufacturer. Any unfit method or using incompatible material may cause product damage, burst and serious injury.

Do not install the unit in a potentially explosive or flammable atmosphere.

Failure to do so could result in fire.

Do not insert your fingers or other objects into the air conditioner indoor or outdoor unit, rotating parts may cause injury.



Do not touch the outdoor unit during lightning, it may cause electric shock.

Do not expose yourself directly to cold air for a long period to avoid excess cooling.

Do not sit or step on the unit, you may fall down accidentally.



Remote control



Do not allow infants and small children to play with the remote control to prevent them from accidentally swallowing the batteries.

Power supply



Do not use a modified cord, joint cord, extension cord or unspecified cord to prevent overheating and fire.




To prevent overheating, fire or electric shock:

- Do not share the same power outlet with other equipment.
- Do not operate with wet hands.
- Do not over bend the power supply cord.
- Do not operate or stop the unit by inserting or pulling out the power plug.



Use complete power supply cord without joining. In unavoidable circumstances that complete power supply cord without joining is impossible, use an approved connection means (for example: socket and plug).



If the supply cord is damaged, it must be replaced by the manufacturer, service agent or similarly qualified persons in order to avoid a hazard.

It is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD) to prevent electric shock or fire.

To prevent overheating, fire or electric shock:

- Insert the power plug properly.
- Dust on the power plug should be periodically wiped with a dry cloth.

Stop using the product if any abnormality/failure occurs and disconnect the power plug or turn off the power switch and breaker. (Risk of smoke/fire/electric shock)

Examples of abnormality/failure

- The ELCB trips frequently.
- Burning smell is observed.
- Abnormal noise or vibration of the unit is observed.
- Water leaks from the indoor unit.
- Power cord or plug becomes abnormally hot.
- Fan speed cannot be controlled.
- The unit stops running immediately even if it is switched on for operation.
- The fan does not stop even if the operation is stopped.

Contact your local dealer immediately for maintenance/repair.



This equipment must be earthed to prevent electrical shock or fire.



Prevent electric shock by switching off the power supply and unplugging:

- Before cleaning or servicing,
- When extended non-use, or
- During abnormally strong lightning activity.



CAUTION

Indoor unit and outdoor unit



Do not wash the indoor unit with water, benzene, thinner or scouring powder to avoid damage or corrosion at the unit.

Do not use for preservation of precise equipment, food, animals, plants, artwork or other objects. This may cause quality deterioration, etc.

Do not use any combustible equipment in front of the airflow outlet to avoid fire propagation.

Do not expose plants or pet directly to airflow to avoid injury, etc.

Do not touch the sharp aluminium fin, sharp parts may cause injury.



Do not switch ON the indoor unit when waxing the floor. After waxing, aerate the room properly before operating the unit.

Do not install the unit in oily and smoky areas to prevent damage to the unit.

Do not dismantle the unit for cleaning purpose to avoid injury.

Do not step onto an unstable bench when cleaning the unit to avoid injury.

Do not place a vase or water container on the unit. Water may enter the unit and degrade the insulation. This may cause an electric shock.

Do not open window or door for long time during operation, it may lead to inefficient power usage and uncomfortable temperature changes.



Prevent water leakage by ensuring drainage pipe is:

- Connected properly,
- Kept clear of gutters and containers, or
- Not immersed in water

After a long period of use or use with any combustible equipment, aerate the room regularly.

After a long period of use, make sure the installation rack does not deteriorate to prevent the unit from falling down.

Remote control



Do not use rechargeable (Ni-Cd) batteries. It may damage the remote control.



To prevent malfunction or damage of the remote control:

- Remove the batteries if the unit is not going to be used for a long period of time.
- New batteries of the same type must be inserted following the polarity stated.

Power supply




Do not disconnect the plug by pulling the cord to prevent electric shock.

nanoe-G generator




Do not touch the sharp pin which may cause injury.

How to use



Indicator


- POWER
- TIMER
- AUTO COMFORT
- nanoe-G
- POWERFUL
- QUIET



Not used in normal operations.

Press to restore the remote control to default setting.

To adjust airflow direction



- Do not adjust the flap by hand.

To adjust fan speed



- For AUTO, the indoor fan speed is automatically adjusted according to the operation mode.

To switch between POWERFUL/QUIET



POWERFUL:

To reach temperature quickly

- This operation stops automatically after 4 hours.

QUIET:

To enjoy quiet operation

- This operation reduces airflow noise.

To save energy



- When manual AIR SWING  is selected, the ECONAVI operations will be cancelled.

To maximise comfort



- When manual AIR SWING  is selected, the AUTO COMFORT operations will be cancelled.


To purify the air

nanoe-G

- nanoe-G starts automatically when the unit is turned on with .
- nanoe-G will not start automatically during ON timer if the unit has been turned off by .
- Can be activated even when the unit is turned off. In this condition, the unit will operate as a fan with AUTO fan speed and flap swing.

To set the timer

2 sets of ON and OFF timers are available to turn ON or OFF the unit at different preset times.



① Select ON or OFF timer

- Each time pressed: $\text{ON} \rightarrow \text{OFF} \rightarrow \text{Cancel}$

② Set the time

③ Confirm

Example:
OFF at 22:00

OFF  OFF  0:00

 OFF  22:00

 OFF  22:00

SET  OFF  22:00

- To cancel ON or OFF timer, press  or  to select respective ON or OFF then press .
- If timer is cancelled manually or due to power failure, you can restore the timer again by pressing  or  to select respective ON or OFF then press .
- The nearest timer setting will be displayed and will activate in sequence.
- Timer operation is based on the clock set in the remote control and repeats daily once set. For clock setting, please refer to Quick Guide.

How to use
English

Note

 ,  ,  , 

- Can be activated in all modes and can be cancelled by pressing the respective button again.

 ,  , 

- Cannot be selected at the same time.

To learn more...

Operation mode

- AUTO** : During operation mode selection the POWER indicator blinks.
COOL : Provides efficient comfort cooling to suit your needs.
DRY : Unit operates at low fan speed to give a gentle cooling operation.

Energy saving temperature setting

Operating the unit within the recommended temperature range may save energy.

COOL : 26.0 °C ~ 28.0 °C / 79 °F ~ 82 °F.

Air flow direction

In COOL/DRY mode:

If AUTO is set, the flap swings left/right and up/down automatically.

Auto restart control

If power is resumed after a power failure, the operation will restart automatically after a period of time with previous operation mode and airflow direction.

- This control is not applicable when TIMER is set.

nanoe-G in-filter deactivation

Depending on the unit's accumulated operation time, nanoe-G in-filter deactivation may activate only once a day after the unit turned off.

To remove the moisture left in the internal parts, the fan will operate for 30 minutes with flap opened slightly. This process only applicable when the unit is operated in COOL/DRY mode before turned off. Then, nanoe-G deactivates viruses/bacteria on the filter for 2 hours with fan stopped and flap closed.

Do not turn off the power supply during this operation. After power failure, this operation will not resume.

ECONAVI and AUTO COMFORT

■ Econavi with intelligent eco sensors

Intelligent eco sensors detect potential waste of energy using the human activity sensor and sunlight sensor.

■ Auto Comfort with intelligent eco sensors

Intelligent eco sensors detect potential waste of energy using the human activity sensor and auto adjust the temperature and fan speed during high activity level to provide comfort environment.


The human activity sensor scans areas of heat source and movement in a room.

- Based on area activeness, flap will adjust its position automatically.
- The human activity sensor is influenced by the location of the indoor unit, the movement speed of human/non-human activity, temperature range, etc.
- The human activity sensor may mistakenly detect non-human activity and source of heat, such as pets, or may not detect the human activity or source of heat if the person stays motionless.
- Do not place large objects near the sensor and keep away heating units or humidifier from the sensor's detections area.

The sunlight sensor detects changes in sunlight intensity in the room. It reduces the waste of energy under less sunlight conditions.


5 Features

① Temperature wave



Rhythmic temperature-controlled pattern to save energy without sacrificing comfort.

② Area search




Human activity sensor detects presence/absence of human beings and the movement speed of human activities minimising the required amount of energy.


③ Activity detection



④ Absence detection



⑤ Sunlight detection



Adjusts power to changes in sunlight intensity.

To learn more...

English

Operating conditions

Use this air conditioner in the temperature range indicated in the table.

Temperature °C (°F)		Indoor		Outdoor	
		DBT	WBT	DBT	WBT
COOL	Max.	32 (89.6)	23 (73.4)	43 (109.4)	26 (78.8)
	Min.	16 (60.8)	11 (51.8)	16 (60.8)	11 (51.8)

DBT: Dry bulb temperature, WBT: Wet bulb temperature

Cleaning instructions

To ensure optimal performance of the unit, cleaning has to be carried out at regular intervals. Dirty unit may cause malfunction and you may see nanoe-G indicator blinks or error code "H99". Please consult authorised dealer.

- Switch off the power supply and unplug before cleaning.
- Do not touch the aluminium fin, sharp parts may cause injury.
- Do not use benzine, thinner or scouring powder.
- Use only soap (≈ pH 7) or neutral household detergent.
- Do not use water hotter than 40 °C / 104 °F.

Indoor unit

Wipe the unit gently with a soft, dry cloth. Coils and fans should be clean for at least every 6 months by an authorised dealer.




Human activity sensor

Do not hit or violently press or poke it with a sharp object. This can lead to damage and malfunction.

Outdoor unit


Clear debris that surround the unit. Clear any blockage from drain pipe.




Front panel

Wash gently and dry.

Remove the front panel




Close it securely



③ Close down.

④ Press both ends and center of the front panel.


Indoor unit



nanoe-G Generator

Once every 2 weeks

- Clean with dry cotton bud.
- Do not touch during operation.




Air filters

Once every 2 weeks


- Wash/rinse the filters gently with water to avoid damage to the filter surface.
- Dry the filters thoroughly under shade, away from fire or direct sunlight.
- Replace any damaged filters.



Remove air filter



Attach air filter



Insert into the unit

Troubleshooting

The following symptoms do not indicate malfunction.

Symptom	Cause
POWER indicator blinks before the unit is switched on.	• This is a preliminary step in preparation for the operation when the ON timer has been set. • When ON Timer is set, the unit may start earlier (up to 15 minutes) before the actual set time in order to achieve the desired temperature on time.
TIMER indicator is always on.	• The timer setting repeats daily once set.
Operation is delayed a few minutes after restarting.	• The delay is a protection to the unit's compressor.
Indoor fan stops occasionally during automatic fan speed setting.	• This helps to remove the surrounding odour.
The room has a peculiar odour.	• This may be due to damp smell emitted by the wall, carpet, furniture or clothing.
Cracking sound during operation.	• Changes of temperature caused the expansion/contraction of the unit.
Water flowing sound during operation.	• Refrigerant flow inside the unit.
Mist emerges from indoor unit.	• Condensation effect due to cooling process.
Outdoor unit emits water/steam.	• Condensation or evaporation occurs on pipes.
Discoloration of some plastic parts.	• Discoloration is subject to material types used in plastic parts, accelerated when exposed to heat, sun light, UV light or environmental factor.
Dust may have collected around the front panel, grilles and wall surrounding the unit after extended use.	• The dust accumulation is due to air purification effect of negative ions from nanoe-G. Remove the dust regularly with a clean dampened cloth.


Check the following before calling for servicing.

Symptom	Check
Operation in COOL mode is not working efficiently.	• Set the temperature correctly. • Close all doors and windows. • Clean or replace the filters. • Clear any obstruction at the air inlet and air outlet vents.
Noisy during operation.	• Check if the unit has been installed at an incline. • Close the front panel properly.
Remote control does not work. (Display is dim or transmission signal is weak.)	• Insert the batteries correctly. • Replace weak batteries.
The unit does not work.	• Check if the circuit breaker is tripped. • Check if timers have been set.
The unit does not receive the signal from the remote control.	• Make sure the receiver is not obstructed. • Certain fluorescent lights may interfere with signal transmitter. Please consult authorised dealer.

Troubleshooting

When...

■ The remote control is missing or a malfunction has occurred



1. Raise the front panel.
2. Press the button once to use in AUTO mode.
3. Press and hold the button until you hear 1 beep, then release to use in forced COOL mode.
4. Press the button again to turn off.

■ The indicators are too bright

- To dim or restore the unit's indicator brightness, press  and hold for 5 seconds.

■ Conducting a seasonal inspection after extended non-use

- Check the remote control batteries.
- Check that there is no obstruction around the air inlet and outlet vents.
- Use Auto OFF/ON button to select COOL operation. After 15 minutes of operation, it is normal to have the following temperature difference between the air inlet and outlet vents:

COOL: $\geq 8^{\circ}\text{C}$ / 14.4°F

■ The units are not going to be used for a long period of time

- Activate nanoe-G operation for 2~3 hours as an alternative to remove moisture left in the internal parts thoroughly to prevent mould growth.
- Turn off the power supply and unplug.
- Remove the remote control batteries.

NON SERVICEABLE CRITERIAS


TURN OFF THE POWER SUPPLY AND UNPLUG then please consult an authorised dealer when in following conditions:

- Abnormal noise during operation.
- Water/foreign particles have entered the remote control.
- Water leaks from Indoor unit.
- Circuit breaker switches off frequently.
- Power cord becomes unnaturally warm.
- Switches or buttons are not functioning properly.

How to retrieve error codes

If the unit stops and the TIMER indicator blinks, use the remote control to retrieve the error code.

- ① Press for 5 seconds
- ② Press until you hear beep sound, then write down the error code
- ③ Press for 5 seconds to quit checking
- ④ Turn the unit off and reveal the error code to authorised dealer



• For certain errors, you may restart the unit for limited operation if there are 4 beeps when operation starts.

Diagnostic display	Abnormality/Protection control
H 00	No memory of failure
H 11	Indoor/outdoor abnormal communication
H 12	Indoor unit capacity unmatched
H 14	Indoor intake air temperature sensor abnormality
H 15	Outdoor compressor temperature sensor abnormality
H 16	Outdoor current transformer (CT) abnormality
H 17	Outdoor suction temperature sensor abnormality
H 19	Indoor fan motor mechanism lock
H 21	Indoor float switch operation abnormality
H 23	Indoor heat exchanger temperature sensor 1 abnormality
H 24	Indoor heat exchanger temperature sensor 2 abnormality
H 25	Indoor ion device abnormality
H 26	Minus ION abnormality
H 27	Outdoor air temperature sensor abnormality
H 28	Outdoor heat exchanger temperature sensor 1 abnormality
H 30	Outdoor discharge pipe temperature sensor abnormality
H 31	Abnormal swimming pool sensor
H 32	Outdoor heat exchanger temperature sensor 2 abnormality
H 33	Indoor/outdoor misconnection abnormality
H 34	Outdoor heat sink temperature sensor abnormality
H 35	Indoor/outdoor water adverse current abnormality
H 36	Outdoor gas pipe temperature sensor abnormality
H 37	Outdoor liquid pipe temperature sensor abnormality
H 38	Indoor/outdoor mismatch (brand code)
H 39	Abnormal indoor operating unit or standby units

Diagnostic display	Abnormality/Protection control
H 41	Abnormal wiring or piping connection
H 50	Ventilation fan motor locked
H 51	Ventilation fan motor locked
H 52	Left-right limit switch fixing abnormality
H 58	Indoor gas sensor abnormality
H 59	Eco sensor abnormality
H 64	Outdoor high pressure sensor abnormality
H 67	nanoe abnormality
H 70	Light sensor abnormality
H 71	DC cooling fan inside control board abnormality
H 72	Abnormality tank temperature sensor
H 97	Outdoor fan motor mechanism lock
H 98	Indoor high pressure protection
H 99	Indoor operating unit freeze protection
F 11	4-way valve switching abnormality
F 16	Total running current protection
F 17	Indoor standby units freezing abnormality
F 18	Dry circuit blocked abnormality
F 87	Control box overheat protection
F 90	Power factor correction (PFC) circuit protection
F 91	Refrigeration cycle abnormality
F 93	Outdoor compressor abnormal revolution
F 94	Compressor discharge pressure overshoot protection
F 95	Outdoor cooling high pressure protection
F 96	Power transistor module overheating protection
F 97	Compressor overheating protection
F 98	Total running current protection
F 99	Outdoor direct current (DC) peak detection

* Some error code may not be applicable to your model. Consult authorised dealer for clarification.

提供快速製冷，最佳的舒適度，
清新的空氣及更有效的節省能源


人類活動感測器

- 範圍搜尋
- 活動感測
- 不在場感測

陽光感測器及遙控接收器


在室內機遙控接收器的 8 米範圍內
使用遙控器。

靈活地連接單一分體式
或多聯分體式空調器以
滿足您的需求。有關於
完整產品功能，請參閱
目錄冊。




簡易指南

裝入電池



- ① 拉出遙控器的背蓋。
- ② 裝入 AAA 或 R03 電池。
- ③ 把蓋關上。


A 時間設定



- ① 按下 並設置時間

• 持續按下 大約 5 秒以顯示 12 小時 (am/pm) 或 24 小時的格式。

- ② 確認 .



感謝您購買 Panasonic 空調器。

目錄

安全措施	16-17
如何使用	18-19
學習更多... ..	20-21
清洗說明	22
故障檢修	23-25
信息	26

附件

- 遙控器
- AAA 或 R03 電池 × 2
- 遙控器托架
- 用於遙控器托架的螺釘 × 2

本操作說明書裡的圖解僅作為說明用途，並且可能與實際產品有所區別。若因為產品改進而發生變更，恕不另行通知。

B 基本操作

- ① 按 **MODE** 選擇所需的模式。


AUTO → COOL → DRY

- ② 按 **OFF/ON** 開始/停止操作。



- 請注意 **OFF** 指示燈顯示在顯示屏以啟動本機。

- ③ 選擇所需要的溫度。



選擇範圍：
16.0 °C ~ 30.0 °C /
60 °F ~ 86 °F.

- 持續按下  大約 10 秒以轉換為 °C 或 °F 的格式顯示溫度。

安全措施

為了防止個人傷害，危害其他人或財物的損失，請遵守以下指示：
因不遵守以下指示導致的錯誤操作將引起傷害或損壞，其嚴重程度分類如下：
此設備不適合用于公共場所。


	警告 此標識所示的行為有可能導致嚴重傷害或死亡。
---	------------------------------------

	注意 此標識所示的行為有可能導致傷害或財產損失。
---	------------------------------------

要遵守的指示按下列符號分類：

	此符號表示被禁止的行為。
---	--------------

	此符號表示務必執行的行為。
---	---------------



警告

室內機及室外機

 此裝置不適合殘疾、感應欠佳或智障，經驗與知識不足的人士(包括兒童)使用。除非負責其安全的監督人從旁監督或指示如何正確使用此裝置。務必監督兒童以確保他們不會玩弄本機。

請諮詢授權經銷商或專業人員清潔內部零件，修理、安裝、拆卸和重新安裝本機。安裝及處理不當將導致漏電，觸電或火災。

請向授權經銷商或專業人員確認有關任何指定製冷劑類型之運用。使用所指定以外的製冷劑類型會導致產品損壞，爆裂並導致傷害等。

 切勿使用除製造商建議以外的方法來加速除霜過程或清理。
任何不適當的方法或使用不相容的材料可能導致產品損壞，爆裂和嚴重傷害。

切勿將本機安裝在爆炸或可燃性的環境中。
否則會導致火災。

切勿把手指或其他物件插入空調器的室內或室外機以免受到旋轉部件傷害。



閃電時切勿觸摸室外機，否則會導致觸電。

切勿長時間受冷氣流直接吹拂以免過冷。

切勿坐或踩踏在本機上以免意外摔跤。



遙控器

 切勿讓嬰兒和小孩玩遙控器以免不小心吞下電池。

電源

 切勿採用改裝電線，接合電線，延長電線或非指定的電線，以免過熱及火災。




為免過熱，火災或觸電：

- 切勿與其他設備共用一個電源插座。
- 切勿用潮濕的手操作。
- 切勿過度扭曲電線。
- 切勿以插入或拉出插頭的方式來操作或停止本機。



請採用不須進行接合的完整電線。在沒有完整電線而必須接合電線的情況下，請採用合格的連接配件(例如插座及插頭)。



如果電線損壞，必須由製造商、其服務代理商或具有同等資格的合格人員進行更換以免遭受危害。

強烈建議您安裝接地漏電電源斷路器 (ELCB) 或殘餘電流裝置 (RCD) 以免觸電或火災。

為免過熱，火災或觸電：

- 妥當插入插頭。
- 務必定時用乾布擦掉插頭上的灰塵。

當出現任何異常/故障時，請停止使用本機，拔出電插頭或關掉電源開關及斷路器。

(煙霧/火災/觸電危險)

異常/故障舉例

- 接地漏電電源斷路器 (ELCB) 頻繁跳開。
- 出現燒焦味。
- 本機出現異常噪音或振動。
- 室內機漏水。
- 電線或插頭變得異常熱。
- 無法控制風量。
- 本機立即停止運轉，雖然已經打開準備操作。
- 雖然已經停止操作，風扇仍然不停止轉動。

立即諮詢經銷商以進行保養/修理。



本設備必須接地以免觸電或火災。



為免觸電，請在下列情況時關閉電源並拔出插頭：



- 清洗或維修之前，
- 長期不使用時，或
- 異常強烈閃電時。



注意

室內機及室外機



切勿用水、苯、稀釋劑或潔亮粉末清洗室內機以免損壞或腐蝕本機。

切勿充作其他用途，如貯藏食物、動物、植物、藝術品或其他物件。否則會破壞品質等。

切勿在氣流出口使用任何易燃器具以免引起火災。

切勿讓植物或寵物受冷氣流直接吹拂以免損傷等。

切勿觸摸尖銳的鋁散熱片以免受到尖銳部件傷害。



當在地面打蠟時切勿開啟室內機。打蠟完畢之後，請先讓房間良好通風再操作本機。

切勿將本機安裝在油煙重的場所以免損壞本機。

切勿拆卸本機來進行清洗工作以免受傷。

當清洗本機時切勿踩踏在不穩固的架子上以免受傷。

切勿將花瓶或水容器放置在本機上。水會進入本機而導致絕緣受到破壞。這會引起觸電。

在操作過程中切勿長時間打開窗戶或門，否則可能導致低效的電力使用和不舒適的溫度變化。



為免漏水，請確保排水軟管：

- 連接正確，
- 不受通道及容器阻擋，或
- 不浸在水裏

長時間使用或與其他易燃設備一起使用後請定時讓房間通風換氣。

長期使用後，請注意安裝支架是否有損壞以免主機墜落。

遙控器



切勿使用可充電電池 (Ni-Cd)。它會損壞遙控器。



為免遙控器失靈或損壞：

- 如果準備長期不使用本機，務必將電池取出。
- 務必採用同類型的新電池並對準電極插入。

電源




切勿以抽拉電線的方式來拔除插頭以免觸電。

nanoe-G 產生器




請勿觸摸尖角，以免造成傷害。

如何使用



指示燈

- POWER
- TIMER
- AUTO COMFORT
- nanoe-G
- POWERFUL
- QUIET



在正常操作下
不使用。

按下以恢復遙控
器的出廠設定。

調整垂直風向




朝上方向

AIR SWING



朝橫方向



- 切勿用手調節葉片。

調節風量



- 至於 AUTO (自動) 運轉，室內風扇風量將依據運轉模式自動調節。

轉換於 POWERFUL/QUIET (強勁/安靜) 之間



POWERFUL (強勁):

迅速達到設定溫度

- 此運轉在 4 小時後自動停止。

QUIET (安靜):

享受安靜運轉

- 此功能將減低氣流噪音。

節省能源



- 當手動 AIR SWING (空氣擺動) 被選取時，ECONAVI (節能導航) 運轉將被取消。

為獲取最佳的舒適度



- 當手動 AIR SWING (空氣擺動) 被選取時，AUTO COMFORT (自動舒適) 運轉將被取消。


以淨化空氣

nanoe-G

- 用  啟動本機時 nanoe-G 功能會自動開始操作。
- 如果已透過  關閉本機，在 ON (開機) 定時器期間，nanoe-G 功能不會自動開始操作。
- 此功能在本機關閉時依然可以啟動。在此情況下，本機將 AUTO (自動) 調節風量及擺動葉片並送風。

設定預約時間

具有兩組 ON (開機) 及 OFF (關機) 定時預約時間以在不同的預約時間下 ON (啟動) 或 OFF (關閉) 主機。



① 選擇 “ON (開機)” 或 “OFF (關機)” 模式
• 每次按下時：
① → ② → Cancel

② 設定時間

③ 確認

舉例：在 22:00 OFF (關機)

OFF  ① 0:00

   ① 22:00

SET OFF ① 22:00

- 按下  或  以選擇相關的 ① 或 ② 然後按下  以取消開機或關機定時預約時間。
- 如果自行取消定時預約或因為發生停電而被取消，您可按下  或  以選擇相關的 ① 或 ② 然後按下  以恢復之前的設定。
- 最接近的定時操作設置會顯示，並且會順序啟動。
- 定時預約機能將依據遙控器所設定的時間操作，並且一旦被設定後會每天重複操作。至於時鐘設定，請參閱簡易指南。

備註

, , , 

- 可以在任何模式中操作。再分別按下相關的按鈕即可取消操作。

, , 

- 無法被同時選取。

學習更多...

運轉模式

AUTO (自動)：在運轉模式選擇時，POWER (電源) 指示燈將閃爍。

COOL (製冷)：提供高效舒適製冷，以滿足您的需求。

DRY (除濕)：空調以低速運轉，進行極為柔和的製冷運轉。

節能溫度設定

在所建議的溫度範圍內操作本機可為您節省能源。

COOL (製冷): 26.0 °C ~ 28.0 °C / 79 °F ~ 82 °F.

氣流方向

在 **COOL/DRY (製冷/除濕)** 模式下：

如果設定為 **AUTO (自動)** 風向時，葉片將自動向左/右及向上/下擺動。

自動重新啟動控制

如果在電源中斷後恢復電源，在一段時間後運轉將自動重新啟動於先前的運轉模式和風向。

- 當 **TIMER (定時器)** 被設置時此功能將無效。

nanoe-G 濾塵網抗菌功能

視本機的累積操作時間而定，在關閉主機後 **nanoe-G 濾塵網抗菌功能** 可能會每天只啟動一次。

為排除留在內部機件的濕氣，葉片將在稍微打開的情況下操作風扇送風 30 分鐘。此流程只會在主機關閉之前操作 **COOL/DRY (製冷/除濕)** 模式方為有效。之後，**nanoe-G** 將於停止風扇送風和關閉葉片的狀態下在濾塵網中消滅病毒/細菌達 2 小時。

切勿在此功能操作中關閉電源。電源中斷後此功能操作將不恢復。

ECONAVI 及 AUTO COMFORT

■ 採用智能環保感測器的 Econavi

智能環保感測器使用人類活動感測器和陽光感測器檢測潛在的能源浪費。

■ 採用智能環保感測器的 Auto Comfort

智能環保感測器使用人類活動感測器檢測潛在的能源浪費，並在人類在高活動量時自動調節溫度以提供舒適環境。


人類活動感測器也可掃描房間的熱源與活動範圍。

- 基於範圍的活動量，葉片將自動調節其位置。
- 人類活動感測器取決於室內機的位置、人類/非人類活動的移動速度、溫度等。
- 人類活動感測器可能錯誤地檢測非人類活動和熱源 (例如寵物)，或者在人保持不動時可能檢測不到人類活動或熱源。
- 切勿放置任何大型物件於感測器附近，並且別放置製暖器或潮濕器於感測器的感測範圍內。

陽光感測器會檢測室內陽光強度的變化。它可以減少較少陽光條件下的能源浪費。


5 項功能

① 溫度波動




韻律性溫度 - 不犧牲舒適度的受控節能模式。

② 範圍搜尋




人類活動感測器可檢測人類是否在場以及人類活動的移動速度，從而將所需的能源量降至最低。

③ 活動感測



④ 不在場感測



⑤ 陽光感測



根據陽光強度的變化調節功率。

學習更多...

操作條件

在表中所示的溫度範圍內使用此空調器。

溫度 °C (°F)		室內		室外	
		DBT	WBT	DBT	WBT
COOL (製冷)	最高	32 (89.6)	23 (73.4)	43 (109.4)	26 (78.8)
	最低	16 (60.8)	11 (51.8)	16 (60.8)	11 (51.8)

DBT: 乾球溫度, WBT: 濕球溫度

中文


清洗說明

為了確保本機發揮最佳性能，您必須進行定期清洗。本機變頻會導致故障，並出現 nanoe-G 指示燈閃爍或“H99”錯誤代碼。請諮詢授權經銷商。

- 進行清洗前，關掉電源並拔出插頭。
- 切勿觸摸鋁片，尖銳部分會造成傷害。
- 切勿使用苯、稀釋劑或潔亮粉末。
- 僅使用肥皂（ $\approx$ pH 7）或中性家用清潔劑。
- 切勿使用溫度高過 40°C / 104°F 的水。

室內機

使用乾、軟的布輕抹。
線圈和風扇應至少每 6 個月由授權經銷商清洗。



人類活動感測器

切勿用尖銳物件敲打或強烈地按或刺室內機。否則會導致損壞及故障。

室外機


清理本機周圍的雜物。
清除排水軟管的任何堵塞。




正面板

輕洗並弄乾。

取出正面板




確實關上



③ 關閉。

④ 按正面板的兩端和中央。


室內機



nanoe-G 產生器

每 2 星期一次

- 使用乾棉花棒清洗。
- 運轉時切勿觸摸。




空氣過濾器

每 2 星期一次


- 用水輕輕清洗/沖洗過濾網以免損壞過濾網的表層。
- 在陰涼處徹底弄乾過濾網，遠離火源或直射陽光。
- 請更換損壞的過濾網。



取出空氣過濾網



安裝空氣過濾網



裝入主機

故障檢修

以下現象並非表示故障。

現象	原因
在打開主機以前 POWER (電源) 指示燈會閃爍。	- 這是當開機定時預約時間被設定時準備開始操作的初步工作。 - 當設定了定時開機時，為了在您設定的時間內達到您所設定的溫度，空調器會在設定的時間提前運轉 (高達 15 分鐘)。
TIMER (定時器) 的指示燈一直亮。	一旦設定後，定時預約設定會每天重覆操作。
重新啟動後，運轉延遲幾分鐘。	此延遲用於保護本機壓縮機。
在自動風量設定中，室內風扇時開時停。	這是為了排除周圍所發出的異味。
室內有異味。	這可能是牆壁、地毯、家具或衣物散發出來的氣味。
運轉時發出吱嘎噪聲。	溫度變化造成主機膨脹或收縮。
運轉時，聽見類似流水聲。	機內製冷劑流動的聲音。
室內機散發出霧氣。	製冷導致冷凝現象。
室外機滴水/蒸氣。	這是配管表面水蒸氣冷凝或蒸發的現象。
一些塑膠部件變色。	變色是受塑膠部件使用的材料種類影響。當暴露於熱、太陽光線、紫外線或環境因素會加速變色。
長期使用後，灰塵會積累在本機的正面板、格柵和四周牆壁。	灰塵積累的原因是 nanoe-G 的負離子產生的空氣淨化效果。定時用清潔的微濕布來清除灰塵。


在進行維修之前請先檢查以下各項。

現象	檢查
在 COOL (製冷) 模式運轉時無法有效地操作。	- 設定正確溫度。 - 關上所有房門及窗戶。 - 清洗或更換過濾網。 - 移除阻擋空氣吸入或吹出口的任何阻礙物。
運轉時產生噪音。	- 檢查是否裝斜了主機。 - 妥善關閉正面板。
遙控器不操作。 (顯示屏變暗或傳輸信號微弱。)	- 正確地安裝電池。 - 更換微弱的電池。
本機不能啟動。	- 檢查是否是電流斷路器跳開了。 - 檢查是否已設定預約時間。
本機沒有從遙控器收到信號。	- 確認接收器不受阻礙。 - 某種類型的螢光燈可能會影響信號接收。請諮詢授權經銷商。

故障檢修

當。。。。

■ 遙控器丟失或發生故障



1. 向上提起正面板。
2. 按一次按鈕以在 **AUTO**（自動）模式下使用。
3. 持續按下按鈕直到聽見一聲“嗶”，然後鬆開以在強制 **COOL**（製冷）模式下使用。
4. 再按一次按鈕以關閉。

■ 指示燈太亮

- 持續按下  5 秒以調暗或恢復主機的指示燈亮度。

■ 進行長期不使用后的換季檢查

- 檢查遙控器的電池。
- 檢查並確保室內機或室外機的空氣吸入或吹出口順暢無阻。
- 用自動 **OFF/ON**（關/開）按鈕來選擇 **COOL**（製冷）運轉。運轉 15 分鐘後，在正常情況下，室內機空氣吸入及吹出口的溫差為：**COOL（製冷）: $\geq 8^{\circ}\text{C}$ / 14.4°F**

■ 長期不使用本機

- 啟動 **nanoe-G** 運轉 2 至 3 小時是徹底排除留在內部機件的濕氣，以防止微菌滋生。
- 關閉電源並拔出插頭。
- 取出遙控器的電池。

不可維修的情況

若出現以下情況，請關閉電源並拔出插頭，然後諮詢授權經銷商：


- 運轉時發出異常噪音。
- 有水/異物進入遙控器。
- 室內機漏水。
- 電源斷路器經常跳閘。
- 電線異常發熱。
- 開關鈕或按鈕不能正常操作。

如何檢索錯誤代碼

如果主機停止操作及 **TIMER** (定時器) 指示燈閃爍，用遙控器檢索錯誤代碼。

① 按下 5 秒

③ 按下 5 秒即可退出故障診斷模式



② 按下直到您聽見“嗶”聲，然後抄下錯誤代碼

④ 關閉空調並將故障代碼告知授權經銷商

• 至於某些錯誤代碼，在運轉啟動時如果您聽見 4 聲嗶聲可重新啟動主機於某些限制運轉。

診斷顯示	異常/保護控制
H 00	沒有故障的記憶
H 11	室內/室外異常通訊
H 12	室內機容量不匹配
H 14	室內進氣溫度感應器異常
H 15	室外壓縮機溫度感應器異常
H 16	室外電流變壓器 (CT) 異常
H 17	室外吸氣溫度感應器異常
H 19	室內風扇馬達機制鎖定
H 21	室內浮球開關操作異常
H 23	室內熱交換器溫度感應器 1 異常
H 24	室內熱交換器溫度感應器 2 異常
H 25	室內離子裝置異常
H 26	減低 ION (離子) 異常
H 27	室外空氣溫度感應器異常
H 28	室外熱交換器溫度感應器 1 異常
H 30	室外排放管溫度感應器異常
H 31	異常的游泳池感應器
H 32	室外熱交換器溫度感應器 2 異常
H 33	室內/室外錯誤連接異常
H 34	室外散熱器溫度感應器異常
H 35	室內/室外水逆流異常
H 36	室外氣管溫度感應器異常
H 37	室外液管溫度感應器異常
H 38	室內/室外不匹配 (品牌代碼)
H 39	異常的室內操作機或預備機
H 41	異常的電線或管道連接
H 50	抽風機馬達鎖定

診斷顯示	異常/保護控制
H 51	抽風機馬達鎖定
H 52	左右限位開關固定異常
H 58	室內氣體感應器異常
H 59	環流感應器異常
H 64	室外高壓感應器異常
H 67	nanoe 異常
H 70	光傳感器異常
H 71	控制板內的直流製冷風扇異常
H 72	蓄水器溫度感應器異常
H 97	室外風扇馬達機制鎖定
H 98	室內高壓保護
H 99	室內操作機防凍保護
F 11	四路閥門開關異常
F 16	總運行電流保護
F 17	室內預備機凍結異常
F 18	小功率電路阻塞異常
F 87	控制箱過熱保護
F 90	功率因數校正 (PFC) 電路保護
F 91	製冷循環異常
F 93	室外壓縮機異常變革
F 94	壓縮機排氣壓力過衝保護
F 95	室外製冷高壓保護
F 96	功率晶體模塊過熱保護
F 97	壓縮機過熱保護
F 98	總運行電流保護
F 99	室外直流 (DC) 高峰偵測

* 某些錯誤代碼不適用於您的型號。請諮詢授權經銷商以了解狀況。

English

Information for Users on Collection and Disposal of Old Equipment and used Batteries



[Information on Disposal in other Countries outside the European Union]

These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.



Note for the battery symbol (bottom two symbol examples):

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.

Pb

中文

關於用戶回收與丟棄舊設備及電池的信息



[非歐共體國家的處理信息]

這些符號僅有效於歐洲共同體。如果您要丟棄這些物件，請諮詢您的當地政府或經銷商並詢問正確的丟棄方式。



電池符號的注意事項（底部兩個符號舉例）：

此符號可與化學符號綜合使用。在此情況下，它須符合制定給該化學的使用條件。

Pb

Memo/備忘錄

Panasonic Corporation
1006 Kadoma, Kadoma City,
Osaka, Japan
Website: <http://www.panasonic.com>

© Panasonic Corporation 2017

Printed in Malaysia

ACXF55-17770
FA1217-0